

TS3000 series Robot Controller

TS3000	SCARA / LINEAR system
TS3100	SCARA / LINEAR / 6AXIS system
TSL3000	SCARA system
TSL3100	6AXIS system

INSTRUCTION MANUAL

USER PARAMETER MANUAL

Notice

- Make sure that this instruction manual is delivered to the final user of Toshiba Machine's industrial robot.
- Before operating the industrial robot, read through and completely understand this manual.
- After reading through this manual, keep it nearby for future reference.

TOSHIBA MACHINE CO., LTD.

Copyright 2014 by Toshiba Machine Co., Ltd.
All rights reserved.

No part of this document may be reproduced in any form without obtaining prior written permission from Toshiba Machine Co., Ltd.

The information contained in this manual is subject to change without prior notice to effect improvements.

Preface

This manual describes the machine parameters for small-size SCARA robot controller "**TS3000 series**" and "**TSL3000 series**".

The machine parameters are registered in the controller under the text file named "**USER.PAR**". Like the SCOL program, they can be edited by the program editor. For use of the program editor, see the Operator's Manual.

Table of Contents

	Page
[U00] EXTERNAL MODE FULL CONTROL	4
[U01] SYSTEM BASE COORDINATE	4
[U02] NOWAIT MODE FOR MULTI TASK	5
[U03] DEFAULT MOVESYNC MODE.....	5
[U04] TEACHING MODE OVERRIDE	6
[U05] OVERRIDE ON SLOW SPEED SIGNAL	6
[U06] SERIAL PORT SETTING	7
[U07] SPECIFY SIGNAL FOR EXTSELECT	8
[U08] RESERVE	9
[U09] AUXILIARY SIGNAL	10
[U10] DEFAULT TEACHING MODE.....	12
[U11] I/O MODE	13
[U12] EXTEND I/O SETTING	14
[U13] SEQUENCE PARAMETER.....	15
[U14] SOFTWARE LIMIT	16
[U15] PLC ALARM	17
[U16] FIELD BUS.....	18
[U17] PASSWORD	19
[U18] ACCEL LIMIT FUNCTION.....	20
[U19] MASTER MODE.....	20
[U20] PLC COMMUNICATION REGISTER ADDRESS.....	21
[U21] SERIAL DATA ERROR CHECK	22
[U22] COMMON DATA & PROGRAM FILE FUNCTION SETUP	23
[U23] BYPASS FUNCTION PARAMETER	23
[U24] SPEED LIMIT FUNCTION	25
[U25] FUNCTION SELECT SWITCH	26
[U26] PAYLOAD FOR MANUAL OPERATION.....	31
[U27] STRINGIO.PAR RESPONSE COMMAND ADDITION SETTING	32
[U28] PASS COMMAND MODE SW	33
[U29] COMMUNICATION SIZE OF ALARM HISTORY	33
[U30] 3-AXIS ORIGIN CHANGE FUNCTION	34
[U31] JOG SPEED CHANGE FUNCTION	36
[U32] JOGGING SPEED[%]	37
[U33] INCHING SPEED[%].....	38
[U34] INCHING AMOUNT [MM] [DEG]	39
[U35] SEQUENCE FUNCTION SELECT SWITCH	40
EXTRNSEL.PAR SETTING PROGRAM FILE FOR FILE SELECT SIGNAL LINE.....	41

Specify 0.0 0.0 0.0 0.0 0.0 0.0 when you wish to match the BASE coordinate system and the WORLD coordinate system.

[U02] NOWAIT mode for multi task

NOWAIT specified for multitasks

[U02]NOWAIT MODE FOR MULTI TASK (0:COMMON, 1:INDIVIDUAL) = 0

Set values	= 1	Independent control for each task (NOWAIT improved type) (Toshiba Machine's recommendation)
	= 0	Common use by tasks (NOWAIT previous type)
Data type:	Integer type	
Data unit:	None	
Data range:	0 or 1	
Number of data:	1	
Description:	Specify a multitasking operation mode. Specify whether system variable "NOWAIT" is controlled independently for each task or commonly used by tasks during multitasking operation. However, when the "NOWAIT" is commonly used by tasks, the SCOL programming becomes complicated. It is recommended to adopt a mode for setting independently for each task.	

[U03] DEFAULT MOVESYNC MODE

Default of MOVESYNC

[U03] DEFAULT MOVESYNC MODE (0:ENABLE, 1:DISABLE) = 1
--

Set values	= 0	Motion command synchronous mode (ENABLE MOVESYNC)
	= 1	Motion command asynchronous mode (DISABLE MOVESYNC)
Data type:	Integer type	
Data unit:	None	
Data range:	0 or 1	

Number of data: 1

Description: Specify the synchronous or asynchronous mode for a motion command.
Specify selection of the motion command synchronous mode that the system executes just before the next motion command and waits until positioning is completed during programmed operation or selection of the motion command asynchronous mode that the system pre-read and executes up to four (4) motion commands. In the motion command asynchronous mode, pass motion cannot be performed even if "PASS" is set to ENABLE.

[U04] TEACHING MODE OVERRIDE

Teaching mode override

[U04] TEACHING MODE OVERRIDE = 20

Set value: Example 20 (which is a value limited to 20% of the maximum speed)

Data type: Integer type

Data unit: %

Data range: 1 ~ 100

Number of data: 1

Description: Specify the maximum speed of motion in teaching mode.

* If 0 is set, operation is performed at the internal parameter speed that was set at shipping.

[U05] OVERRIDE ON SLOW SPEED SIGNAL

Override slow-speed command

[U05] OVERRIDE ON SLOW SPEED SIGNAL (0 - 100)[%] = 25
--

Set value: Example 25 (which is a value limited to 25% of the maximum speed)

Data type: Integer type

Data unit: %
 Data range: 1 ~ 100
 Number of data: 1
 Description: Specify the speed at the command of slow speed (system input signal). Specify robot operating speed at the input of a slow-speed command signal. When a slow-speed command signal is input during automatic operation, specify at how many percent of the maximum speed the robot operates.

* If 0 is set, operation is performed at the internal parameter speed that was set at shipping.

[U06] SERIAL PORT SETTING

Serial port

Specify the communication port (i.e., COM port).

```

[U06] SERIAL PORT SETTING
{Speed }(38400, 19200, 9600, 4800, 2400, 1200)
{Character}(7, 8)
{Parity }(0:Without, 1:Odd, 2:Even)
{Stop bit }(1, 2)
{COM1}
= 9600  8  0  1
{HOST}
= 9600  8  0  1
  
```

Set value: {COM1}
 = (Speed) (Character length) ← Setting of COM1 port
 (Parity) (Stop bit length)
 {HOST}
 = (Speed) (Character length) ← Setting of HOST port
 (Parity) (Stop bit length)

Data type:
 Data unit:
 Data range:
 Number of data: 2*4

Description: (Speed): Specify data communication speed. Select among six (6) speeds that follow.

38400 : 38400 bps

19200 : 19200 bps

9600 : 9600 bps

4800 : 4800 bps

2400 : 2400 bps

1200 : 1200 bps

(Character length): Specify the character length to be transferred.

8: 8 bits

7: 7 bits

(Parity): Specify the parity of characters to be transferred.

0: Without parity

1: Odd parity

2: Even parity

(Stop bit length): Specify the stop bit length of characters to be transferred.

1: Stop bit 1

2: Stop bit 2

For details, see the Communication Manual.

[U07] SPECIFY SIGNAL FOR EXTSELECT

Setting of file select signal line.

[U07] SPECIFY SIGNAL FOR EXTSELECT

{Signal No }(1 -)

{Bit length }(1 - 8)

= 101 4

Set value: Example 101 4 Four (4) extended input signals numbered 101 ~ 104.

Data type: Integer type

Data unit:

Data range: At least eight (8) successive signals from standard inputs 1 ~ 16, extended inputs 101 ~ 164, or field bus inputs 301 ~ 364.

Number of data: 2

Description: Set file selected signal line.

Specify the input signal from outside the controller to select an execution file, using the input signal.

Specify up to eight (8) consecutive input signals from standard inputs 1 ~ 64, extended inputs 101 ~ 164 or field bus inputs 301 ~ 364. To be more specific, specify the leading number of input signals to be used and the number of signals to be used by discriminating them by space.

= Specify in order (Signal No.), (Bit length).

(Signal No.): Specify the leading number of input signals to be used.

Set value 1 ~ 64 (Standard input)

101 ~ 164 (Extended input)

301 ~364 (Field bus input)

Select the number from the above inputs.

(Bit length): Specify the number of signals to be used.

Set value TS3000: 1~8

[U08] RESERVE

Reserve parameter

[U08] RESERVE

= 0

Description: Set the reserve parameter as "0" because it is not currently set.

[U09] AUXILIARY SIGNAL**Set the auxiliary signal display (AUX)**

```
[U09] AUXILIARY SIGNAL
  {Type }(0:Single, 1:Double)
  {Signal No. }(1 - 24)
  {Signal Name}(Max 10character)
= 0  201  "Hand out 1"
= 0  202  "Hand out 2"
= 0  203  "Hand out 3"
= 0  204  "Hand out 4"
= 0    0  "Not  Use  "
= 0    1  "Dout 1    "
= 0    2  "Dout 2    "
= 0    3  "Dout 3    "
= 0    4  "Dout 4    "
= 0    5  "Dout 5    "
= 0    6  "Dout 6    "
= 0    7  "Dout 7    "
= 0    8  "Dout 8    "
= 0    9  "Dout 9    "
= 0   10  "Dout 10   "
= 0   11  "Dout 11   "
= 0   12  "Dout 12   "
= 0   13  "Dout 13   "
= 0   14  "Dout 14   "
= 0   15  "Dout 15   "
```

Example 1: Set value = 0 201 "Hand out 1"

Output signal 201 is registered as the single solenoid and the display name is Hand out 1.

Example 2: Set value = 11 "out 1"

Output signals 1 and 2 are registered as the double solenoid and the display name is out 1.

Data type:

Data unit:

Data range:

Number of data: 3*20

Description: Specify the data on the auxiliary signal display so that the robot I/O can be set ON and OFF from the teach pendant.

= Specify in order (Solenoid), (Signal No.), (Signal name).

Output signals for twenty (20) contacts can be specified.

(Solenoid): When the double solenoid is connected with output signals, the output signals should be controlled exclusively.

When "Double" is specified, two (2) successive output signals are controlled exclusively.

0 : Single solenoid (normal output)

1 : Double solenoid (Two (2) consecutive output signals are output exclusively.)

Caution: This is the setting for auxiliary signal operation through the teach pendant. Even if the double solenoid is selected, signals are not output exclusively at automatic operation. Exclusive output of signals should be specified in the program.

Even if the double solenoid is specified, all output signals are OFF at power ON.

(Signal No.): Specify the number of output signal to be used.

When "Double" is specified, specify the smaller number of two (2) consecutive output signals. Output signals that can be specified are as follows:

0	Not registered.		
1	(DOUT1)	~ 16 (DOUT16)	Standard output
101	(DOUT101)	~ 164 (DOUT164)	Extended digital output
201	(HANDOUT1)	~ 214 (HANDOUT4)	Hand output

(Signal name): Specify the signal name displayed. Up to ten (10) characters can be set.

[U10] DEFAULT TEACHING MODE**Initial value of manual guide**

[U10] DEFAULT TEACHING MODE

{Coordinate = 0: Joint, 1: Tool, 2: Work, 3: World}

{Speed = 0: Low, 1: Mid, 2: High}

{Jog mode = 0: Jog, 1: Inching, 2: Free}

= 3 0 0

Example: Set value = 3 0 0 (World, Low, Jog)

Data type: Integer type

Data unit:

Data range:

Number of data: 3

Description: Specify the initial value of manual operation in the teaching mode.

(Coordinate): Specify the guidance coordinate system selected as default.

- 0 : Joint
- 1 : Tool
- 2 : Work
- 3 : World

(Rate): Specify the guide rate selected as default.

- 0 : Low
- 1 : Mid
- 2 : High

(Jog mode): Specify the guidance mode selected as default.

- 0 : Jog
- 1 : Inching
- 2 : Free

[U11] I/O MODE**I/O mode**

[U11] I/OMODE

{Default/User}{0:Default, 1:User RAM, 2:User FLASH, 3:User backup RAM)

= 0

Set value: = (I/O operation mode)

Data type: Integer type

Data unit:

Data range: 0 ~ 3

Number of data: 1

Description: Specify the I/O operation mode.

I/Os specified in the program are calculated by sequence, which are then input or output. This parameter selects the storage area of such sequence program.

TS3000 allows to back up the RAM area also by battery.

Specify "1" for the parameter, which should be changed to "3" after the sequence debug. (Value 1 or 3 is saved in the same area.

When "1" is specified, the sequence is cleared by power OFF/ON.)

[U12] EXTEND I/O SETTING

Extended I/Os

[U12] EXTEND I/O SETTING

{Use/Not Use} (0:Not Use, 1:Use)

{Not Use}

{Not Use}

= 0 0 0

= 0 0 0

Set value: = (Use/Not Use) (Reserved) (Reserved)

← Setting of distribution I/O node 0.

= (Use/Not Use) (Reserved) (Reserved)

← Setting of distribution I/O node 1.

Data type: Integer type

Data unit:

Data range: 0 or 1

Number of data: 3*2

Description: Set the extended I/Os.

For the extended I/Os, two (2) nodes (node 1 and node 2) can be connected.

Node 0 is set in the upper level, and node 1 in the lower level.

(Use/Not use): Specify the presence or absence of extended I/O.

0 : Absence of extended I/O

1 : Presence of extended I/O

(Reserved): Reserved for future system extension.
Specify zero (0).

(Reserved): Reserved for future system extension.
Specify zero (0).

[U13] SEQUENCE PARAMETER**Sequence parameter**

[U13] SEQUENCE PARAMETER (User I/O mode only)

= 0 0 0 0 0 0 0 0

Set value: = (R510) (R511) (R512) (R513) (R514) (R515) (R516) (R517)

Data type: Integer type

Data unit:

Data range: 0 ~ 1

Number of data: 8

Description: Set the values of internal display that can be utilized as the contact inputs in the user's created sequence program.
This parameter is effective only when "User" (user create sequence) is selected by [U11] I/O MODE.

[U14] SOFTWARE LIMIT

Software limit

[U14] SOFTWARE LIMIT [deg][mm]							
{+ Direction}							
=	116.0	141.0	121.0	361.0	0.000	0.000	0.000
{- Direction}							
=	-116.0	-141.0	-1.0	-361.0	0.000	0.000	0.000

{+ Direction}

Set values: TS3000 = (1 axis + joint limit) (2 axis...) (3 axis...)
 (4 axis...) (5 axis...) (Reserved) (Reserved)
 (Reserved)

TS3000 (6-axis) = (1 axis + joint limit) (2 axis...) (3 axis...)
 (4 axis...) (5 axis...) (6 axis...) (7 axis...)
 (8 axis...)

Data type: Real number type

Data unit: deg or mm

Data range:

Number of data: 8

Description: Specify the software limit values (JLIMIT).
 Setting of + (plus) joint limit (+ soft stroke limit). Values set in the
 joint limit setting change mode (JLIMIT) are saved.

{- Direction}

Set values: TS3000 = (1 axis - joint limit) (2 axis...) (3 axis...)
 (4 axis...) (5 axis...) (Reserved) (Reserved)
 (Reserved)

TS3000 (6-axis) = (1 axis - joint limit) (2 axis...) (3 axis...)
 (4 axis...) (5 axis...) (6 axis...) (7 axis...)
 (8 axis...)

Data type: Real number type

Data unit: deg or mm

Data range:

Number of data: 8

Description: Specify the software limit values (JLIMIT).
 Setting of - (minus) joint limit (- soft stroke limit). Values set in the
 joint limit setting change mode (JLIMIT) are saved.

[U15] PLC ALARM**PLC alarms****[U15] PLC ALARM**

= "8-269 PLC alarm 01	"
= "8-270 PLC alarm 02	"
= "8-271 PLC alarm 03	"
= "8-272 PLC alarm 04	"
= "4-077 PLC alarm 05	"
= "4-078 PLC alarm 06	"
= "4-079 PLC alarm 07	"
= "4-080 PLC alarm 08	"
= "1-037 PLC alarm 09	"
= "1-038 PLC alarm 10	"
= "1-039 PLC alarm 11	"
= "1-040 PLC alarm 12	"
= "1-041 PLC alarm 13	"
= "1-042 PLC alarm 14	"
= "1-043 PLC alarm 15	"
= "1-044 PLC alarm 16	"

Example: Set value = "8-269 PLCALM01"

Data type:

Data unit:

Data range: Up to 32 alphanumeric characters

Number of data: 16

Description: Specify the PLC alarm message.

The PLC alarm is an alarm which can be generated by sequence when "User" is selected for "[U11] I/O mode". In this setting, message for each of such alarm can be specified.

Specify an alarm message to be displayed in the area flanked by the quotation marks ("). Though up to thirty-two (32) characters can be specified, the leading six (6) characters are used to identify the alarm number, and a total of twenty-six (26) characters can be used for the message. DO NOT change the leading six (6) characters (alarm code) which are used to identify the alarm number.

[U16] FIELD BUS**Field bus**

[U16] FIELDDBUS {type / Node Addr / Speed / Byte Order} = -1 -1 -1 -1

Example: Set value = 37 4 1 0, = (Type) (Node) (Transmission rate) (Type of master)

Data type: Integer type

Data unit:

Data range:

Number of data: 4

Description: Specify the field bus. The field bus is an optional function.

(Type): Specify the type of the field bus.

-1 : Without field bus option (initial value)

1 : Profibus

37 : DeviceNet

144 : CCLINK

(Node): Specify the node address of the field bus.

This address should not be identical with another device in the same network. The setting range differs with the type of the field bus.

-1 : Without field bus option (initial value)

0 ~ 127 : Profibus

0 ~ 63 : DeviceNet

1 ~ 64 : CCLINK

(Transmission rate): Specify the transmission rate. Setting of Profibus is unnecessary. Make it coincide with the master transmission rate.

Specify the transmission rate of DeviceNet.

0: 125 kbps

1: 250 kbps

2: 500 kbps

Specify the transmission rate of CCLINK.

0: 156 kbps

1: 625 kbps

- 2: 2.5 Mbps
 3: 5 Mbps
 4: 10 Mbps
- (Type of master): Specify the type of the field bus master.
 The bit string (endian) differs with the master.
 Make the value identical with the master.
- 0 : 16-bit big endian
 (DRM21, DeviceNet made by OMRON)
 (A1SJH, CCLINK made by MELSEC)
- 1 : 16-bit little endian
 (S7 315DP2, PROFIBUS made by
 SIEMENS)
- 2 : 32-bit big endian
 3 : 32-bit little endian

* For details, see the Fieldbus Slave Manual.

[U17] PASSWORD

Password

[U17] Password

= " "

Set value: = (Password up to 8 characters)

Data type:

Data unit:

Data range:

Number of data: 1

Description: The password is a character string when using the password function. The password function is optional.

[U18] ACCEL LIMIT FUNCTION

Function for limiting acceleration and deceleration according to Z -axis height

[U18] ACCEL LIMIT FUNCTION

= 0

Set value: = (Function effective/ineffective)

Data type: Integer type

Data unit:

Data range: 0 or 1

Number of data: 1

Description: When the parameter is made valid, acceleration/deceleration is limited according to Z-axis height. This function is effective only for the SCARA robot system.

0: Ineffective function

1: Effective function

[U19] MASTER MODE**Master mode**

[U19] MASTER MODE

= "EXT.SIGNAL"

Set value: = (Specify master mode after the power supply is turned on.)

Data type:

Data unit:

Data range:

Number of data: 1

Description: This function is ineffective for TS3000 series. The master mode is set using the key switch and user parameter [U00].

[U20] PLC COMMUNICATION REGISTER ADDRESS

PLC communication register address

[U20] PLC COMMUNICATION REGISTER ADDRESS

{Current Position/ Alarm/ Master Mode/ Alarm Resetting/ spare/ spare}

= 4 2560 2580 0 0 0

Set value: See the description below.

Data type: Integer type

Data unit:

Data range:

Number of data: 6

Description: This parameter is exclusively used for the die-cast unloading robot.
Communication is done with the TC200 made by Toshiba Machine.

Current Position: Address where the current coordinate of the robot (in the work coordinate system) is to be sent.

Alarm: Address where alarm information is to be sent.

Master Mode: Address where master mode information is to be sent.

Alarm Resetting: Address where alarm reset from the PLC is to be monitored.

spare: Reserved

spare: Reserved

[U21] SERIAL DATA ERROR CHECK**Serial data error check**

[U21] SERIAL DATA ERROR CHECK

{ 0:checked, 1:passed }

= 0

Set value: = (Specify whether there is presence or absence of error check for non-procedural communication and simple procedural communication.)

Data type: Integer type

Data unit:

Data range: 0 or 1

Number of data: 1

Description: This parameter is used as the ON/OFF changeover flag of error check for non-procedural communication and simple procedural communication. Specify zero (0) normally.

- 0: Error checking is carried out for non-procedural communication and simple procedural communication.
- 1: Error checking is not carried out for non-procedural communication and simple procedural communication.

[U22] COMMON DATA & PROGRAM FILE FUNCTION SETUP

Common data and program function setup

[U22] COMMON DATA & PROGRAM FILE FUNCTION SETUP
 { 0:Disable, 1:DATA.TBL, 2:SCOL.PRg }
 = 0

Set value: = (Specify the ON/OFF flag of the common program and common data functions in the SCOL language specifications.)

Data type: Integer type

Data unit:

Data range: 0 ~ 2

Number of data: 1

Description: This parameter serves as the ON/OFF flag of the common program and common data functions in the SCOL language specifications.
 0: Disable
 1: Common data (DATA. TBL)
 2: Common program (SCOL. PRG)

[U23] BYPASS FUNCTION PARAMETER

Bypass operation designation parameter

[U23] BYPASS FUNCTION PARAMETER
 { Function enable SW (0:Disable, 1:M-to & Bypass, 2:Bypass)
 = 0
 { Retract position }
 = 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
 { Z Axis offset parameter }
 = 0.0 0.0

Set value: This function is used only for the SCARA robot system and LCDR robot system. The parameter should be set at zero (0) in other robot system. For details of setting, see the description below.

Data type: Real number type (Function enable SW is integer type.)

Data unit:

Data range:


Number of data: 11

Description: In the M-TO (move to teach point) function, as the robot arm moves directly to the teach point, it may collide with a workpiece present midway.

When this bypass (move to teach point by bypassing) function is made effective, the robot once retracts its hand, moves to just before the target position, then to the target position.


<SCARA robot>

1. Moves by retracting from current position P0 to P0a.
2. "Parallel move + rotation" from position P0a to P1a.
3. Moves by extending from position P1a to P1.



<LCDR robot>

1. Leaves a workpiece.
2. Moves by retracting from current position P0 to P0a.
3. "Parallel move + rotation" from position P0a to P1a.
4. Moves by extending from position P1a to P1.
5. Contacts the workpiece.



- Z-axis offset parameter for LCDR
= -10.0 -10.0

Maximum operation speed limit

Set value:	= (Specify operating speed limit.)
Data type:	Integer type
Data unit:	
Data range:	0 or 1
Number of data:	1
Description:	When this function is made valid, operating speed of the robot is controlled in such a manner that it will not exceed the maximum speed. 0: Disable 1: Enable

[U25] FUNCTION SELECT SWITCH

Selection of enabling or disabling controller functions

[U25] FUNCTION SELECT SWITCH

= 0 0 0 0 0 0

= 0 0 0 0 0 0

= 0 0 0 0 0 0

= 0 0 0 0 0 0

Set value: = (FUNCTION 1) (FUNCTION 2) (FUNCTION 3) (FUNCTION 4)
 (FUNCTION 5) (FUNCTION 6)
 = (FUNCTION 7) (FUNCTION 8) (FUNCTION 9) (FUNCTION10)
 (FUNCTION11) (FUNCTION12)
 = (FUNCTION13) (FUNCTION14) (FUNCTION15) (FUNCTION16)
 (FUNCTION17) (FUNCTION18)
 = (FUNCTION19) (FUNCTION20) (FUNCTION21) (FUNCTION22)
 (FUNCTION23) (FUNCTION24)

Data type: Integer type

Data unit:

Data range: 0 or 1

Number of data: 6*4

Description: This parameter selects ON or OFF of the controller functions. The functions which can be effective are assigned to each element.
 1: Function ON
 0: Function OFF

The effective functions of each element are described below.

Function	Item Name	Description	Setting Example	Supported Systems
(FUNCTION 1)	INPUT character string conversion function	In the INPUT process, this switches the process when a non-numerical character string is received. 0: Function disabled. (Invalid Channel error occurs when a non-numerical character string is received.) 1: Convert to 0 when a non-numerical character string is received. 2: Convert to a user-selected number when a non-numerical character string is received (SCARA system only). For details, see the Communication Manual, section 4.3.	[U25]Function switch = 1 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	All systems
(FUNCTION 2)	Selection of movement method for teaching point movement (MOV-TO)	This switches the operation command in the teaching point movement based on the guidance coordinate status. BYPASS teaching point movement is also identical. 0: All MOVE operations 1: When guidance coordinates are JOINT → MOVE operation When guidance coordinates are TOOL, WORK, or WORLD → MOVES (linear interpolation) operation	[U25]Function switch = 0 1 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	All systems
(FUNCTION 3)	TCmini latch register retain function	In [U11] I/O MODE 2:USER FLASH mode, the register setting is not retained in the same way as 3:USER BACKUP RAM mode. The register retain function in 2:USER FLASH mode is switched by switching the parameters. 0: Not retained (Retained in the same way as before when [U11] is 3) 1: Retained (Not retained when [U11] is 0 or 1)	[U25]Function switch = 0 0 1 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	All systems
(FUNCTION 4)	Output change in I/O and AUX screens	I/O changing from UTILITY → I/O and from UTILITY → AUX screen is allowed in TEACHING MODE only. 0: Conventional support (changing allowed) 1: Editing prohibited (changing allowed in TEACHING mode only)	[U25]Function switch = 0 0 0 1 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	All systems
(FUNCTION 5)	Reserved	0: Disabled 1: Enabled *TS2000/TS1000 has a Fieldbus 128-point expansion function. (TS3000 has 128 fixed points.)	[U25]Function switch = 0 0 0 0 1 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	
(FUNCTION 6)	Reserved	0: Disabled 1: Enabled	[U25]Function switch = 0 0 0 0 0 1 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	
(FUNCTION 7)	8-280 Buzzer and fault signal	This is a function that turns off the buzzer sound by an external signal and that turns off the alarm for the CT3 safety relay operation. When "8-280 Safety SW relay ON" is generated, 0: Output is performed 1: Output is not performed (No alarm output or buzzer output is performed.) *In the TS2000, this is the PLC register synchronization function.	[U25]Function switch = 0 0 0 0 0 0 = 1 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	All systems
(FUNCTION 8)	8-281 Buzzer and fault signal	This is a function that turns off the buzzer sound by an external signal and that turns off the alarm for the CT3 safety relay operation. When "8-281 Emergency SW relay ON" is generated, 0: Output is performed 1: Output is not performed (No alarm output or buzzer output is performed.) *In the TS2000 SCARA robot, this is a vision conveyor synchronization workpiece clamp error prevention function. In the TS2000 Cartesian robot, this is a zero suppress cancel function.	[U25]Function switch = 0 0 0 0 0 0 = 0 1 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	All systems

Function	Item Name	Description	Setting Example	Supported Systems
(FUNCTION 9)	Reserved	0: Disabled 1: Enabled *In the TS2000 SCARA robot, this is a conveyor synchronization simulation function. In the TS2000 Cartesian robot, this is a I/O specify number function during distribution.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 1 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	
(FUNCTION10)	Reserved	0: Disabled 1: Enabled *In the TS2000 Cartesian robot, this is a I/O specify number function during output.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 1 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	
(FUNCTION11)	Reserved	0: Disabled 1: Enabled *In the TS2000 Cartesian robot, this is an INPUT command data conversion function.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 1 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0	
(FUNCTION12)	Reserved	0: Disabled 1: Enabled *In the TS2000 Cartesian robot, this is a function that substitutes 0 into missing sections of the INPUT data.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 1 = 0 0 0 0 0 0 = 0 0 0 0 0 0	

* Note that even if the functions are identical to the TS2000, the FUNCTION numbers may differ for certain functions.

Function	Item Name	Description	Setting Example	Supported Systems
(FUNCTION 13)	Speed limit function by Z-axis area	Function for limiting the speed at the Z-axis. This sets the Z-axis speed limit area and the Z-axis speed limit area speed using the parameter [R35] Speed limit by Z axis area. 0: Disabled 1: Enabled	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = <u>1</u> 0 0 0 0 0 = 0 0 0 0 0 0	Cartesian
(FUNCTION 14)	PRINT output zero suppress cancel function	When output display to the teach pendant is performed by the PRINT command, when the data is 11 characters or less, spaces are displayed, and the data is right-justified. When this function is enabled, the spaces are not displayed, and the data is left-justified. 0: Disabled 1: Enabled	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 <u>1</u> 0 0 0 0 = 0 0 0 0 0 0	SCARA Cartesian
(FUNCTION 15)	Special function for specific customers: I/O specify number during distribution	This turns on the specified DOUT bit during distribution (during robot operation). Also, after distribution is completed, the specified DOUT bit is turned off. 0: Disabled Value other than 0: Enabled (Setting value 1 to 64, 101 to 164, 301 to 364) If the same number as FUNCTION16 is specified, the function is disabled.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 <u>1</u> 0 0 0 = 0 0 0 0 0 0	SCARA Cartesian
(FUNCTION 16)	Special function for specific customers: I/O specify number during output	This turns on the specified DOUT bit when the robot controller and PC are connected by COM1 and data is being output to COM1. Also, after output is completed, the specified DOUT bit is turned off. 0: Disabled Value other than 0: Enabled (Setting value 1 to 64, 101 to 164, 301 to 364) If the same number as FUNCTION15 is specified, the function is disabled.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 <u>1</u> 0 0 = 0 0 0 0 0 0	SCARA Cartesian
(FUNCTION 17)	Special function for specific customers: Execution command (character string) conversion function from external device	0: Disabled 1: Enabled (Once the execution command that was set in STRINGIO.PAR is sent from an external device to the robot controller by COM1, this function turns on the DIN information output that is set in STRINGIO.PAR or DOUT for a fixed period of time.)	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 <u>1</u> 0 = 0 0 0 0 0 0	
(FUNCTION 18)	Substituting 0 into insufficient sections of INPUT data	When waiting for input data at INPUT COM1, if the number of loaded data is less than the number of specified variables, a wait is performed for data input that was not received. When this function is enabled, the input wait status is canceled, and the missing data is filled by 0. 0: Disabled 1: Enabled	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 <u>1</u> = 0 0 0 0 0 0	SCARA Cartesian
(FUNCTION 19)	Tool flange distance display function	This adds the tool flange distance to the WORLD and WORK screens of the POS screen of the UTILITY. The tool flange distance is displayed only when this function is enabled. 0: Disabled 1: Enabled *Function available in TS3000 only.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = <u>1</u> 0 0 0 0 0	SCARA
(FUNCTION 20)	Reserved	0: Disabled 1: Enabled *PLC override function in TS2000	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 <u>1</u> 0 0 0 0	

Function	Item Name	Description	Setting Example	Supported Systems
(FUNCTION 21)	Reserved	0: Disabled 1: Enabled *Special function for specific customers used by (Da Ji) in TS2000	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 <u>1</u> 0 0 0	
(FUNCTION22)	Support for lowercase in PRINT command	When this function is enabled, output by the PRINT command is output unchanged in lowercase. (Previously, lowercase was converted to uppercase when output by the PRINT command.) Example: (Previously): PRINT "test",CR → "TEST" is output (Function enabled): PRINT "test",CR → "test" is output 0: Disabled, 1: Enabled (Data sent and received by TSPC is not converted to uppercase.)	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 <u>1</u> 0 0	SCARA Cartesian
(FUNCTION23)	MOVE-MOVE S PASS function	When this function is enabled, MOVE and other joint interpolation commands and MOVES/C and other linear/circular interpolation commands can be connected by PASS. (Except for MOVEJ and DELAY, this is enabled in the PASS section for all operation commands.) 0: Disabled 1: Enabled *TS3000 only function.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 <u>1</u> 0	SCARA 6-axis
(FUNCTION24)	Buzzer sound when alarm generated	Because the TSL3000 does not have an operation panel, no method is available for stopping the buzzer except from the teach pendant. The buzzer sound can be disabled by enabling this function. The buzzer sound is enabled by default. 0: Buzzer sound is on. 1: Buzzer sound is off. *TS3000 only function.	[U25]Function switch = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 0 = 0 0 0 0 0 <u>1</u>	All systems

* Note that even if the functions are identical to the TS2000, the FUNCTION numbers may differ for certain functions.

[U26] PAYLOAD FOR MANUAL OPERATION

Payload for manual operation (Kg, mm)

[U26] PAYLOAD FOR MANUAL OPERATION
 {PAYLOAD parameter for manual operation[Mass(Kg),Offset(mm)]}
 = 0.0 0.0 0.0 0.0 0.0 0.0 0.0

Setting: =(MASS)(Gx)(Gy)(Gz)(Lx)(Ly)(Lz)


Data format: Real number type

Data units:

Data range:

Data count: 7

Description: This sets the PAYLOAD value during manual guidance.
 (MASS): <Mass> The mass of the load applied to the end of the robot is specified in kilogram units.
 (Gx) to (Gz): <Center of gravity offset> The distance from the center of gravity of the load applied to the end of the robot to the tool center at the tip is specified in millimeter units.
 (Gx): <Center of gravity offset in X direction>
 (Gy): <Center of gravity offset in Y direction>
 (Gz): <Center of gravity offset in Z direction>
 (Lx) to (Lz): <Workpiece size> The size of the loaded robot workpiece is specified in millimeter units.
 (Lx): <Size of workpiece in X direction>
 (Ly): <Size of workpiece in Y direction>
 (Lz): <Size of workpiece in Z direction>



[U27] STRINGIO.PAR Response command addition setting**STRINGIO.PAR response command setting (special function for wafer transfer system)**

<p>[U27] STRINGIO.PAR Response command addition setting {0:Both 1:command only 2:sign only} = 0 {Reception response sign} = "-" {Processing completion sign} = ">"</p>

{0:Both 1:command only 2:sign only}Setting: = **(Response command type)**

Data format: Integer type

Data units: None

Data count: 1

Description: This sets the response command type.

0: Added symbol + command

1: Command

2: Added symbol

{Reception response sign}Setting: = **(Response command type)**

Data format: Character type

Data units: None

Data count: 1

Description: This sets the response command addition data when receiving of the command is completed and the specified DOUT ON is completed.

The setting response is 1 uppercase character.

{Processing completion sign}Setting: = **(Response command type)**

Data format: Character type

Data units: None

Data count: 1

Description: This sets the response command addition data when sending of the data is completed and the specified DOUT OFF is completed.

The setting response is 1 uppercase character.

* This function is enabled when FUNCTION 17 of [U25] FUNCTION SELECT SWITCH is enabled.

[U28] PASS COMMAND MODE SW

PASS operation mode switching function

[U28] PASS COMMAND MODE SW
 {0:PASS PRIORITY MODE 1:NO WAIT MODE}
 = 0

- Setting: **= (Specifies the PASS operation mode)**
 Data format: Integer type
 Data units:
 Data range: 0 or 1
 Data count: 1
 Description: This function is used to select whether to perform the PASS operation after completing PASS path generation or without completing PASS path generation.
- 0: PASS operation is performed after path generation is completed.
 - * The PASS operation is performed, but if the program processing time is long between PASS operation commands, a WAIT may be generated before starting the PASS operation (for compatibility with previous versions).
 - 1: The PASS operation is performed without waiting for completion of PASS path generation.
 - * The PASS operation immediately after the WAIT MOTION \geq 100 command can no longer be performed.

[U29] COMMUNICATION SIZE OF ALARM HISTORY

Alarm history display switching function

[U29] COMMUNICATION SIZE OF ALARM HISTORY
 {0:256 1:128}
 = 0

- Setting: **=(Specifying display of alarm history)**
 Data format: Integer type
 Data units:
 Data range: 0 or 1
 Data count: 1
 Description: This function is used to select whether the alarm history shows a maximum of 128 items or 256 items.
- * This function is enabled for TSPC versions 1.64 and later. For TSPC versions earlier than 1.64, the alarm history shows a maximum of 128 items.
 - 0: Alarm history shows a maximum of 256 items.
 - 1: Alarm history shows a maximum of 128 items.

[U30] 3-AXIS ORIGIN CHANGE FUNCTION**3-axis origin change function**

[U30] 3-AXIS ORIGIN CHANGE FUNCTION {0:Disabled 1:Enabled} = 0 {RESERVE} = 0.0
--

{0:Disabled 1:Enabled}

Setting: = (Function enable/disable)

Data format: Integer type

Data units:

Data range: 0 or 1

Data count: 1

Description: This changes the 3-axis origin position of the SCARA robot.

0: Function disabled (bottom edge is 0)

1: Function enabled (top edge is 0)

By default, the 3-axis bottom edge has a software limit of "0",
but when this function is enabled, the 3-axis top edge is set to 0.

This function is enabled for SCARA robot systems only.

{RESERVE}

Setting:

Data format: Real number type

Data units:


Data range:

Data count: 1

Description: System reserved.

Additional description

*For the position of the 3-axis top edge, the 3-axis origin is shifted using the [U16] 3-axis positive (+) software limit value (all numbers after the decimal point are rounded off). If the [U16] positive software limit value is set larger than the mechanical stroke, the origin is shifted by the stroke value that was set internally.



Notes

This function shifts the origin based on the setting value for [U18]. If [U18] is changed, the Z-axis position also changes.

When this function is enabled ([U30] is set to 1: Enabled), all origin setting related functions are disabled. To use an origin setting related function, disable this function ([U30] is set to 0: Disabled).

Functions disabled when [U30] is set to 1: Enabled

- SOFT LIMIT screen
- ZERO POSITION screen
- REORIG screen
- MKORG screen

[U31] JOG SPEED CHANGE FUNCTION**Jog speed change function**

[U31] JOG SPEED CHANGE FUNCTION
{0:Disabled 1:Enabled}
= 0

Setting: = **(Function enable/disable)**

Data format: Integer type

Data units:

Data range: 0 or 1

Data count: 1

Description: This is a function that enables any user-selected setting for the jog speed, inching speed, and inching amount.

0: Function disabled (Robot operates using the internal parameters that were set at shipping.)

1: Function enabled (The jog speed, inching speed, and inching amount that were set in user parameters [U32] to [U34] are applied.)

* Robot operation is performed at the same speed as before (internal parameters that were set at shipping) for teaching point movement and BYPASS, which change the jog speed.

[U32] JOGGING SPEED[%]

Jogging speed

[U32] JOGGING SPEED								
{RECTANGULAR COORDINATE [%]}								
=	10							
=	5							
=	1							
{JOINT COORDINATE [%]}								
=	8	8	5	10	10	0	0	0
=	5	5	3	5	5	0	0	0
=	1	1	1	1	1	0	0	0

{ RECTANGULAR COORDINATE }

Setting: = (Jog speed: High)
 = (Jog speed: Medium)
 = (Jog speed: Low)

Data format: Integer type

Data units: %

Data range: 1 to 100

Data count: 1*3 (High, Medium, Low)

Description: The movement speed when performing jog guidance in the world coordinate system, workpiece coordinate system, and tool coordinate system is defined as a percentage (%) value of the maximum speed.

* When set to 0, operation is performed at the internal parameter speed that was set at shipping.

{ JOINT COORDINATE }

Setting: = (1-axis jog speed: High)(2-axis...)(3-axis...)(4-axis...)
 (5-axis...)(6-axis...)(7-axis...)(8-axis...)
 = (1-axis job speed: Medium)(2-axis...)(3-axis...)(4-axis...)
 (5-axis...)(6-axis...)(7-axis...)(8-axis...)
 = (1-axis job speed: Low)(2-axis...)(3-axis...)(4-axis...)(5-axis...)
 (6-axis...)(7-axis...)(8-axis...)

Data format: Integer type

Data units: %

Data range: 1 to 100

Data count: 8*3 (High, Medium, Low)

Description: The movement speed when performing jogging by joint guidance is defined as a percentage (%) value of the maximum speed for each axis.

* When set to 0, operation is performed at the internal parameter speed that was set at shipping.

[U33] INCHING SPEED[%]

Inching speed

[U33] INCHING SPEED									
{RECTANGULAR COORDINATE [%]}									
=	10								
{JOINT COORDINATE [%]}									
=	10	10	10	10	10	0	0	0	

{ RECTANGULAR COORDINATE }

Setting: = **(Inching speed)**
 Data format: Integer type
 Data units: %
 Data range: 1 to 100
 Data count: 1
 Description: The movement speed when performing inching in the world coordinate system, workpiece coordinate system, and tool coordinate system is defined as a percentage (%) value of the maximum speed.

* When set to 0, operation is performed at the internal parameter speed that was set at shipping.

{ JOINT COORDINATE }

Setting: = **(1-axis inching speed)(2-axis...)(3-axis...)(4-axis...)(5-axis...)(6-axis...)(7-axis...)(8-axis...)**
 Data format: Integer type
 Data units: %
 Data range: 1 to 100
 Data count: 8
 Description: The movement speed when performing inching by joint guidance is defined as a percentage (%) value of the maximum speed.

* When set to 0, operation is performed at the internal parameter speed that was set at shipping.

[U34] INCHING AMOUNT [MM] [DEG]

Inching amount

[U34] INCHING AMOUNT								
{RECTANGULAR COORDINATE [MM][DEG]}								
=	1.0							
=	0.5							
=	0.25							
{JOINT COORDINATE [MM][DEG]}								
=	0.10	0.10	1.00	0.10	0.10	0.0	0.0	0.0
=	0.05	0.05	0.50	0.05	0.05	0.0	0.0	0.0
=	0.01	0.01	0.10	0.01	0.01	0.0	0.0	0.0

{ RECTANGULAR COORDINATE }

Setting: = (Inching amount: Large)
= (Inching amount: Medium)
= (Inching amount: Small)

Data format: Real number type

Data units: mm or deg

Data range: 0.0001 to limit value

Data count: 1*3 (Large, medium, small)

Description: This sets the movement amount when performing inching in the world coordinate system, workpiece coordinate system, and tool coordinate system.

* When set to 0, operation is performed at the internal parameter movement amount that was set at shipping.

{ JOINT COORDINATE }

Setting: = (1-axis inching amount: Large)(2-axis...)(3-axis...)(4-axis...)
(5-axis...)(6-axis...)(7-axis...)(8-axis...)
= (1-axis inching amount: Medium)(2-axis...)(3-axis...)(4-axis...)
(5-axis...)(6-axis...)(7-axis...)(8-axis...)
= (1-axis inching amount: Small)(2-axis...)(3-axis...)(4-axis...)
(5-axis...)(6-axis...)(7-axis...)(8-axis...)

Data format: Real number type

Data units: mm or deg

Data range: 0.0001 to limit value

Data count: 8*3 (Large, medium, small)

Description: This sets the inching amount when performing inching by joint guidance.

* When set to 0, operation is performed at the internal parameter movement amount that was set at shipping.

[U35] SEQUENCE FUNCTION SELECT SWITCH

Selection of enabling or disabling sequence function

[U35] SEQUENCE FUNCTION SELECT SWITCH
= 0 0 0 0 0 0 0 0

Setting: = (FUNCTION 1) (FUNCTION 2) (FUNCTION 3) (FUNCTION 4)
(FUNCTION 5) (FUNCTION 6) (FUNCTION 7) (FUNCTION 8)

Data format: Integer type

Data units:

Data range: 0 or 1

Data count: 8

Description: This selects whether functions using the sequence are enabled or disabled.

The function enabled for each element is assigned.

1: Function on, 0: Function off

The parameter function and signal assignments are shown in the table below.

[U35](from left)	Signal name	Function	Description
FUNCTION 1	H118(SEQFSW1)	Fieldbus system signal output	When this function is enabled, the system signal is assigned to the Fieldbus. 0: Disabled, 1: Enabled
FUNCTION 2	H119(SEQFSW2)	Reserved *1	
FUNCTION 3	H11A(SEQFSW3)	Reserved *1	
FUNCTION 4	H11B(SEQFSW4)	Reserved *1	
FUNCTION 5	H11C(SEQFSW5)	Reserved *1	
FUNCTION 6	H11D(SEQFSW6)	Reserved *1	
FUNCTION 7	H11E(SEQFSW7)	Reserved *1	
FUNCTION 8	H11F(SEQFSW8)	Reserved *1	

*1: Reserved for function expansion.

EXTRNSEL.PAR Setting Program File for File Select Signal Line

Specify the program file corresponding to the file select signal line.

COPYRIGHT(C) 2008 BY TOSHIBA MACHINE CO.,LTD.

ALL RIGHTS RESERVED.

EXTERNAL SELECT FILE

*** [00 - 0F] *****

= "PROG00"

= "PROG01"

= "PROG02"

= "PROG03"

= "PROG04"

= "PROG05"

= "PROG06"

= "PROG07"

= "PROG08"

= "PROG09"

= "PROG0A"

= "PROG0B"

= "PROG0C"

= "PROG0D"

= "PROG0E"

= "PROG0F"

*** [10 - 1F] *****

= "PROG10"

= "PROG11"

= "PROG12"

= "PROG13"

The number of effective files differs with the bit length according to the setting of [U07], and the files are assigned to the file select signals in turn, starting with the top file.

Bit length 1:	0	~	1 (binary number)	Two (2) files
Bit length 2:	00	~	11 (binary number)	Four (4) files
Bit length 3:	000	~	111 (binary number)	Eight (8) files
	:		:	
	:		:	
Bit length 8:	00000000	~	11111111 (binary notation)	256 files

Specify the file name following the equal (=) code.

Unless the equal (=) code is specified at the top of the line, it is processed as a comment.

Set value (Example): = "PROG1"

PROG1 is assigned to the file select signal.

